

MB Citaro

Dashboard



- 1 heating control panel for the driver (explanation below)
- 2 Mirror heating (functionless) Symbol appears in the display
- 3 indoor hot water heater
- 4 Electric window lift
- 5 skylight
- 6 parking brake
- 7 Emergency
- 8 interior lighting
- 9 vehicle lights
- 10 ASR switch
- 11 Warnblinker
- 12 Status panel
- 13 driver information display
- 14-stop brake
- 15 School travel switch
 - Left blinking turns it off
- 16 Door keys
- 17 Door Lock
- 18 Door release (only with automatic doors)
- 19 gear selection buttons

- 20 automatic door lock door 2
- 21 Automatic door lock door 3
- 22 Automatic Kneeling (doors must be closed)
- 23 Manual Kneeling
 - If doors are closed: tap briefly, then open doors
 - If doors are already open: keep the button pressed for 3 seconds
- 24 Quit button
 - Ends OBD mode
- 25 System / Info button
 - System: Gets OBD mode / switches to the next system
 - Info: Gets information about the respective system
- 26 display change key
 - Upper button: changes display information upper field. Press and hold to permanently display the current menu
 - Lower button: Switches between outside temp and consumption (only facelift)
- 27 deactivate retarder
- 28 Retarder permanently active
- 29 Notheben
- 30 switches for roof air conditioning (not adjustable)
- 31 Switch for lifting the car body

Heating panel



- 1 air distribution controller for cockpit
- 2 temperature selector for cockpit
- 3 blower controls for cockpit
- 4 driver's air conditioner (controllable with 1, 2, 3)
- 5 recirculation / fresh air
- 6 Dehumidification for the entire bus
 - Air conditioning and interior heating are included
- switched on
- 7 heater

Revision #1

Created 30 July 2019 08:12:45 by Gameburrow

Updated 30 July 2019 08:32:59 by Gameburrow